

GENERAL COMMENTS

It is essential that the portable BADMINTON court surface is cleaned after each match.

MAINTENANCE

- Remove all court line tapes, markings and floor graphics as necessary.
- Remove loose dirt with broom or vacuum.
- Wash floor with a neutral detergent by low speed scrubbing machine fitted with nylon brushes or red pad. Gerflor recommends a maximum fluid consumption rate of 2L water / neutral detergent solution per 100m².

RECOMMENDATION

ROTOWASH scrubbing machine or similar, with counter rotating cylindrical brushes, which remove the water/detergent mix from the surface as the machine passes.

For further enquiries regarding the maintenance of Gerflor products, please contact your Gerflor Technical Manager.

